

# POWER CRAWL SPACE STABILIZER POST

## Installation

**STEP 1.** Excavate hole and prepare footing base with engineered fill.



**Step 2:** Place pre-cast footing in place in the hole and level.



**Step 3:** Cut galvanized steel pier to the appropriate length.



**Step 4:** Assemble steel column and components then connect to the beam and floor joists.



**Step 5:** Tighten the system into place. This will stabilize the beams and potentially lift the above floor and walls back to level position.



**Step 6:** System may be installed with a crawlspace vapor barrier.

